

# Novell ZENworks®

10

[www.novell.com](http://www.novell.com)

INSTALLATION GUIDE

October 25, 2007



Novell®

## Legal Notices

Novell, Inc. makes no representations or warranties with respect to the contents or use of this documentation, and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. Further, Novell, Inc. reserves the right to revise this publication and to make changes to its content, at any time, without obligation to notify any person or entity of such revisions or changes.

Further, Novell, Inc. makes no representations or warranties with respect to any software, and specifically disclaims any express or implied warranties of merchantability or fitness for any particular purpose. Further, Novell, Inc. reserves the right to make changes to any and all parts of Novell software, at any time, without any obligation to notify any person or entity of such changes.

Any products or technical information provided under this Agreement may be subject to U.S. export controls and the trade laws of other countries. You agree to comply with all export control regulations and to obtain any required licenses or classification to export, re-export or import deliverables. You agree not to export or re-export to entities on the current U.S. export exclusion lists or to any embargoed or terrorist countries as specified in the U.S. export laws. You agree to not use deliverables for prohibited nuclear, missile, or chemical biological weaponry end uses. See the [Novell International Trade Services Web page \(http://www.novell.com/info/exports/\)](http://www.novell.com/info/exports/) for more information on exporting Novell software. Novell assumes no responsibility for your failure to obtain any necessary export approvals.

Copyright © 2007 Novell, Inc. All rights reserved. No part of this publication may be reproduced, photocopied, stored on a retrieval system, or transmitted without the express written consent of the publisher.

Novell, Inc. has intellectual property rights relating to technology embodied in the product that is described in this document. In particular, and without limitation, these intellectual property rights may include one or more of the U.S. patents listed on the [Novell Legal Patents Web page \(http://www.novell.com/company/legal/patents/\)](http://www.novell.com/company/legal/patents/) and one or more additional patents or pending patent applications in the U.S. and in other countries.

Novell, Inc.  
404 Wyman Street, Suite 500  
Waltham, MA 02451  
U.S.A.  
[www.novell.com](http://www.novell.com)

*Online Documentation:* To access the latest online documentation for this and other Novell products, see [the Novell Documentation Web page \(http://www.novell.com/documentation\)](http://www.novell.com/documentation).

## **Novell Trademarks**

For Novell trademarks, see [the Novell Trademark and Service Mark list \(http://www.novell.com/company/legal/trademarks/tmlist.html\)](http://www.novell.com/company/legal/trademarks/tmlist.html).

## **Third-Party Materials**

All third-party trademarks are the property of their respective owners.



# Contents

<b>About This Guide</b>	<b>7</b>
<b>1 Minimum Requirements</b>	<b>9</b>
1.1 Primary Server Requirements . . . . .	9
1.2 Database Requirements . . . . .	12
1.3 LDAP Directory Requirements . . . . .	12
1.4 Managed Device Requirements . . . . .	13
1.5 Inventoried-Only Device Requirements . . . . .	14
1.6 Administration Browser Requirements . . . . .	15
1.7 Installation User Requirements . . . . .	15
<b>2 Installing Configuration Management</b>	<b>17</b>
2.1 Understanding What the ZENworks Installation Does . . . . .	17
2.2 Gathering Information for Installing ZENworks . . . . .	18
2.3 Preinstallation Tasks . . . . .	19
2.3.1 Verifying That the Minimum Requirements Have Been Met . . . . .	19
2.3.2 Creating an Installation DVD from the ISO Download . . . . .	19
2.3.3 Creating External CAs . . . . .	20
2.3.4 Installing an External ZENworks Database . . . . .	21
2.4 Installing ZENworks Configuration Management . . . . .	25
2.4.1 Installation Information . . . . .	27
2.4.2 Manually Installing BusinessObjects Enterprise XI . . . . .	35
2.5 Performing an Unattended Installation of ZENworks Configuration Management . . . . .	37
2.5.1 Creating Your Response File . . . . .	37
2.5.2 Performing an Unattended Installation . . . . .	39
<b>3 Uninstalling Configuration Management</b>	<b>41</b>
<b>A Installation Executable Arguments</b>	<b>43</b>



# About This Guide

This *Novell ZENworks 10 Installation Guide* includes information to help you successfully install a Novell® ZENworks® 10 system. The information in this guide is organized as follows:

- ♦ Chapter 1, “Minimum Requirements,” on page 9
- ♦ Chapter 2, “Installing Configuration Management,” on page 17
- ♦ Chapter 3, “Uninstalling Configuration Management,” on page 41
- ♦ Appendix A, “Installation Executable Arguments,” on page 43

## Audience

This guide is intended for ZENworks Configuration Management administrators.

## Feedback

We want to hear your comments and suggestions about this manual and the other documentation included with this product. Please use the User Comments feature at the bottom of each page of the online documentation, or go to the [Novell Documentation Feedback site \(http://www.novell.com/documentation/feedback.html\)](http://www.novell.com/documentation/feedback.html) and enter your comments there.

## Additional Documentation

ZENworks Configuration Management is supported by other documentation (in both PDF and HTML formats) that you can use to learn about and implement the product. For additional documentation, see the [ZENworks 10 Configuration Management documentation \(http://www.novell.com/documentation/zcm10/index.html\)](http://www.novell.com/documentation/zcm10/index.html).

## Documentation Conventions

In Novell documentation, a greater-than symbol (>) is used to separate actions within a step and items in a cross-reference path.

A trademark symbol (®, ™, etc.) denotes a Novell trademark. An asterisk (\*) denotes a third-party trademark.

When a single pathname can be written with a backslash for some platforms or a forward slash for other platforms, the pathname is presented with a backslash. Users of platforms that require a forward slash, such as Linux\*, should use forward slashes as required by your software.





# Minimum Requirements

# 1

The following sections provide the Novell® ZENworks® 10 Configuration Management minimum requirements for hardware and software:

- ♦ [Section 1.1, “Primary Server Requirements,” on page 9](#)
- ♦ [Section 1.2, “Database Requirements,” on page 12](#)
- ♦ [Section 1.3, “LDAP Directory Requirements,” on page 12](#)
- ♦ [Section 1.4, “Managed Device Requirements,” on page 13](#)
- ♦ [Section 1.5, “Inventoried-Only Device Requirements,” on page 14](#)
- ♦ [Section 1.6, “Administration Browser Requirements,” on page 15](#)
- ♦ [Section 1.7, “Installation User Requirements,” on page 15](#)

---

**IMPORTANT:** All requirements listed in the following sections are minimums. Therefore, later support packs, interim releases, dot releases, and higher version numbers are assumed to be supported. For example, the minimum Primary Server operating system requirement on Windows Server 2003 is listed as SP1, but SP2 or later is also supported.

---

## 1.1 Primary Server Requirements

The network server where you install the Primary Server software must meet the following minimum requirements:

**Table 1-1** *Primary Server Minimum Requirements*

Item	Minimum Requirement
Server Usage	<p>Your server might be capable of handling tasks in addition to the tasks a Primary Server performs for ZENworks Configuration Management. However, we recommend that any server where you install the Primary Server software be used only for ZENworks Configuration Management purposes. For example, you might not want the server to do the following:</p> <ul style="list-style-type: none"><li>♦ Host Novell eDirectory™</li><li>♦ Host Novell Client32™</li><li>♦ Host Active Directory*</li><li>♦ Be a terminal server</li></ul> <p>and so on</p>

Item	Minimum Requirement
Operating System	<p>Windows:</p> <ul style="list-style-type: none"> <li>♦ Windows Server 2003 SP1 Ent x86, x86-64</li> <li>♦ Windows Server 2003 SP1 Std x86, x86-64</li> </ul> <p>BusinessObjects* Enterprise XI Release 2 is supported only on Windows Server 2003 SP1 Ent x86 and Windows Server 2003 SP1 Std x86.</p> <p>Linux:</p> <ul style="list-style-type: none"> <li>♦ SUSE® Linux Enterprise Server 10 (SLES 10) on the 32-bit (x86) and 64-bit (x86-64) architectures (Intel* and AMD* Opteron* processors)</li> </ul> <p>BusinessObjects Enterprise XI Release 2 is supported only on SLES 10 with 32-bit (x86) architecture</p> <ul style="list-style-type: none"> <li>♦ Open Enterprise Server 2 (OES Linux) x86, x86-64</li> </ul>
Hardware	<ul style="list-style-type: none"> <li>♦ Processor: Pentium* IV 2.8 GHz x86, or equivalent AMD or Intel processor</li> </ul> <p>If the Primary Server is running Patch Management, we recommend a fast processor, such as the Intel Core* Duo processor.</p> <ul style="list-style-type: none"> <li>♦ RAM: 1 GB minimum; 2 GB recommended</li> </ul> <p>If you are installing BusinessObjects Enterprise XI Release 2 for ZENworks infrastructure reporting, the minimum is 1.5 GB (512 MB extra).</p> <p>If the Primary Server is running Patch Management, we recommend at least 3 GB of RAM. Running Patch Management is very processor and memory intensive.</p> <ul style="list-style-type: none"> <li>♦ Disk Space: 2 GB minimum for installing; 4 GB recommended for running. Depending on the amount of content you need to distribute, this number can vary greatly.</li> </ul> <p>If you are installing BusinessObjects Enterprise XI Release 2 for ZENworks infrastructure reporting, the minimum is 5 GB (3 GB extra).</p> <p>Because the ZENworks database file and ZENworks content repository can each become very large, you might want a separate partition or hard drive available.</p> <p>For information on changing the default content repository location on a Windows server, see <a href="#">“Content Repository”</a>.</p> <p>For Linux servers, you might want the /opt directory to be located on a large partition. This is where the database (if embedded) and content repository are stored.</p> <ul style="list-style-type: none"> <li>♦ Display resolution: 1024 × 768 with 256 colors</li> </ul>
Hostname Resolution	<p>The server must resolve device hostnames by using a method such as DNS (recommended).</p> <p>Server names must support DNS requirements, such as not having underscores in their names, or ZENworks login fails. Acceptable characters are the letters a-z (uppercase and lowercase), numbers, and the hyphen (-).</p>

Item	Minimum Requirement
IP Address	<p>The server must have a static IP address or a permanently leased DHCP address.</p> <p>Also, an IP address must be bound to all NICs on your target server, because the installation hangs if it is trying to use a NIC that doesn't have an IP address bound to it.</p>
.NET 2.0	<p>The Microsoft* .NET software and its latest updates must be installed and running on the Windows Primary Server in order to install ZENworks Configuration Management. However, you are given the option to launch the .NET installation during installation of ZENworks.</p> <p>Linux Primary Servers have the correct version of Mono® that comes with SLES 10.</p>
TCP Ports	<p>The server must allow traffic on TCP ports 67, 69, 80, 443, 1433, 2638, 3306, 4011, 5550, 5950, and 7628.</p> <p>Port 67 is used by DHCP when sending out PXE requests.</p> <p>Port 69 is for TFTP, and is only UDP.</p> <p>If the server is running other services on ports 80 and 443, such as Apache, or are used by OES2, the installation program asks you for new ports to use.</p> <hr/> <p><b>IMPORTANT:</b> If you plan to use AdminStudio 8.0 ZENworks Edition, it requires that the Primary Server is using ports 80 and 443.</p> <hr/> <p>Port 1433 is used by an MS SQL database server.</p> <p>Port 2638 is used when a Primary Server needs access to another Primary Server where the Sybase* database resides.</p> <p>Port 3306 is used by the MySQL* database embedded in BusinessObjects Enterprise XI.</p> <p>Port 4011 is for proxy DHCP.</p> <p>For Remote Management where the ZENworks Adaptive Agent is running, the server listens on port 5950. If the Remote Management Listener is launched, it listens on port 5550 by default. You can change the port before launching it.</p> <p>Port 7628 is used by the Adaptive Agent.</p>

## 1.2 Database Requirements

If you choose to use a database for the ZENworks Configuration Management database other than the embedded Sybase SQL Anywhere database that is available as the default for ZENworks Configuration Management, the database must meet the following minimum requirements:

**Table 1-2** Database Minimum Requirements

Item	Minimum Requirement
Database Version	Sybase SQL Anywhere 10.0 Microsoft SQL Server 2005 (Enterprise and Standard editions are supported)
Default Character Set	The UTF-8 character set is required
Default Time Zone	UTC is required as the default time zone  <b>IMPORTANT:</b> The server where the external database is installed must have time synchronized with all of the Primary Servers in the Management Zone.
TCP ports	The server must allow Primary Server communication on the database port. The default ports are: <ul style="list-style-type: none"><li>♦ 1433 for MS SQL</li><li>♦ 2638 for Sybase SQL</li></ul>

## 1.3 LDAP Directory Requirements

ZENworks Configuration Management can use existing user sources for assigning content to them. LDAP (Lightweight Directory Access Protocol) is the protocol used by Configuration Management with respect to interacting with users.

**Table 1-3** LDAP Directory Minimum Requirements

Item	Minimum Requirement
LDAP version	LDAP v3
Authoritative user source	<ul style="list-style-type: none"><li>♦ Novell eDirectory™ 8.7.3</li><li>♦ Microsoft Active Directory (Windows 2000 SP4)</li></ul>
LDAP user access	To be able to assign content to users, you must create a read-only connection to an LDAP directory that contains the users. This exposes the users in ZENworks Control Center and enables you to make the assignments. Your LDAP directory is not affected; ZENworks requires only read access to the LDAP directory and stores all assignment information in the ZENworks database. For more information, see <a href="#">“Connecting to User Sources”</a> in the <i>ZENworks 10 Configuration Management Administration Quick Start</i> .

## 1.4 Managed Device Requirements

The ZENworks Adaptive Agent is the management software that is installed on all managed devices, including Primary Servers, but Linux is not supported as a managed device platform. However, when you install the Primary Server software on a Linux server, a portion of the Adaptive Agent is activated so that the System Updates feature can be used on your Linux Primary Servers.

ZENworks Configuration Management can manage any workstations and servers that meet the following minimum requirements:

**Table 1-4** *Managed Device Minimum Requirements*

Item	Minimum Requirement
Operating System	<p>Windows servers:</p> <ul style="list-style-type: none"><li>♦ Windows 2000 Server SP4</li><li>♦ Windows Server 2003 SP1 Ent x86, x86-64</li><li>♦ Windows Server 2003 SP1 Std x86, x86-64</li></ul> <p>Windows workstations:</p> <ul style="list-style-type: none"><li>♦ Windows 2000 Professional SP4 x86</li><li>♦ Windows Embedded XP SP2</li><li>♦ Windows Vista* x86, x86-64 (Business, Ultimate, and Enterprise versions only; Home versions are not supported)</li><li>♦ Windows XP Professional SP2 x86</li><li>♦ Windows XP Tablet PC Edition SP2</li></ul> <p>Thin Client sessions:</p> <ul style="list-style-type: none"><li>♦ Windows 2000 Server SP4 x86</li><li>♦ Windows Server 2003 SP1 x86, x86-64</li></ul>
Hardware	<p>The following are minimum hardware requirements. Use these requirements or the hardware requirements provided with your operating system, whichever is greater.</p> <ul style="list-style-type: none"><li>♦ Processor: Pentium III 700 MHz, or equivalent AMD or Intel</li><li>♦ RAM: 128 MB minimum; 256 MB recommended</li><li>♦ Display resolution: 1024 × 768 with 256 colors</li></ul>
Automatic ZENworks Adaptive Agent Deployment	<p>In order to automatically deploy the Adaptive Agent to your managed devices, the following are required:</p> <ul style="list-style-type: none"><li>♦ Your firewall must allow file and print sharing</li><li>♦ On Windows XP devices, Simple File Sharing must be turned off</li><li>♦ Administrator credentials must be known for the devices in order to install to them</li></ul> <p>For more information, see <a href="#">“Prerequisites for Deploying to a Device”</a> in the <i>ZENworks 10 Configuration Management Discovery and Deployment Reference</i>.</p>

Item	Minimum Requirement
TCP Ports	<p>In order to view the status in ZENworks Control Center of the ZENworks Adaptive Agent for a managed device, ZENworks automatically opens port 7628 on the device if you are using the Windows firewall. However, if you are using a different firewall, you must open this port manually.</p> <p>Port 7628 must also be opened on the device if you want to send a QuickTask to the client from ZENworks Control Center.</p>

## 1.5 Inventoried-Only Device Requirements

ZENworks Configuration Management can only inventory workstations and servers where they also meet certain requirements for installing the ZENworks Adaptive Agent on them. For more information, see the Hardware and TCP Ports sections in [Section 1.4, “Managed Device Requirements,” on page 13](#).

Inventoried-only devices must meet the following minimum requirements:

**Table 1-5** *Inventoried-Only Device Minimum Requirements*

Item	Minimum Requirement
Operating System	<p>Servers:</p> <ul style="list-style-type: none"> <li>♦ AIX 4.3-5.3 IBM pSeries (RS6000)</li> <li>♦ HP-UX 10.20-11.23 HP PA-RISC (HP9000)</li> <li>♦ NetWare® 5.1 <sup>1</sup></li> <li>♦ NetWare 6 <sup>1</sup></li> <li>♦ NetWare 6.5 <sup>1</sup></li> <li>♦ OES (NetWare) <sup>1</sup></li> <li>♦ Red Hat Enterprise Linux 2.1-4.x</li> <li>♦ Solaris 2.6–10 Sun SPARC (32 and 64-bit)</li> <li>♦ SUSE Linux Enterprise Server 8.0-10 (all editions)</li> <li>♦ Windows NT* 4</li> </ul> <p><sup>1</sup> Each NetWare operating system must have its latest Support Pack and the latest patch for <code>libc.nlm</code>.</p> <p>Workstations:</p> <ul style="list-style-type: none"> <li>♦ Mac OS* X 10.2.4</li> <li>♦ Red Hat Linux 7.1-9</li> <li>♦ SUSE Linux Enterprise Desktop 8.0-10 (all editions)</li> <li>♦ Windows 95</li> <li>♦ Windows 98</li> <li>♦ Windows Me</li> </ul>

Item	Minimum Requirement
Inventory Only Module	After installing Configuration Management to your network, you must install this module on the above-listed devices in order to inventory them. For more information, see “ <a href="#">Deploying the Inventory-Only Module</a> ” in the <i>ZENworks 10 Configuration Management Discovery and Deployment Reference</i> .

## 1.6 Administration Browser Requirements

Make sure the workstation or server where you run ZENworks Control Center to administer your system meets the following minimum requirements:

**Table 1-6** Administration Browser Minimum Requirements

Item	Minimum Requirement
Web Browser	<p>The administration device must have one of the following Web browsers installed:</p> <ul style="list-style-type: none"> <li>♦ Internet Explorer 6.0 SP1 (Windows Server 2003, Windows 2000 Server, and Windows 2000)</li> <li>♦ Internet Explorer 6.0 SP2 (Windows XP)</li> <li>♦ Internet Explorer 7 (Windows Vista, Windows Server 2003, and Windows XP)</li> <li>♦ Firefox* 2.0</li> </ul> <p>BusinessObjects Enterprise XI reporting cannot be run in this version of the Web browser. However, it can run on Firefox 1.0.4.</p>
JRE 5.0	In order to run Image Explorer, version 1.5 of the Java* Virtual Machine* (JVM*) must be installed and running on the administration device.
TCP Ports	In order to fulfill a user’s request for a remote session on a managed device, you must open port 5550 on the management console device in order to run Remote Management Listener.

## 1.7 Installation User Requirements

The user running the installation program must have administrator privileges on the device. For example:

**Windows:** Log in as a Windows administrator.

**Linux:** Log in as a non-root user, use the `sux` command to elevate your privileges to root, then run the installation program.





# Installing Configuration Management

# 2

Perform the tasks in the following sections to install Novell® ZENworks® Configuration Management:

- ♦ [Section 2.1, “Understanding What the ZENworks Installation Does,” on page 17](#)
- ♦ [Section 2.2, “Gathering Information for Installing ZENworks,” on page 18](#)
- ♦ [Section 2.3, “Preinstallation Tasks,” on page 19](#)
- ♦ [Section 2.4, “Installing ZENworks Configuration Management,” on page 25](#)
- ♦ [Section 2.5, “Performing an Unattended Installation of ZENworks Configuration Management,” on page 37](#)

---

**WARNING:** If you are only testing or reviewing the product, do not deploy ZENworks Configuration Management into a production environment.

Configuration Management does not require Novell eDirectory™, but instead uses a Management Zone and its own ZENworks Configuration Management database, so you should install to a test server in your network that is not being used for production purposes.

If you want to test managed devices, be aware that installing the ZENworks Adaptive Agent automatically uninstalls the traditional ZENworks agent because a managed device cannot concurrently run different ZENworks agents. However, it does not uninstall the ZENworks Patch Management Agent.

The ZENworks Patch Management Agent and ZENworks Adaptive Agent can coexist. You only need to remove the ZENworks Patch Management agent if you move the Patch Management duties to a ZENworks 10 Configuration Management server.

---

## 2.1 Understanding What the ZENworks Installation Does

ZENworks Configuration Management is installed as a new product. You cannot upgrade to it from a previous version of ZENworks. However, you can migrate your traditional ZENworks data from Novell eDirectory to the new ZENworks Configuration Management database. For more information, see the *[ZENworks 10 Configuration Management ZENworks Migration Guide](#)*.

The first time you install ZENworks Configuration Management, you establish the Management Zone with a Primary Server, which is the first server you install to. Other Primary Servers can then be installed into that Management Zone.

The ZENworks installation program does the following during installation of your first Primary Server:

- ♦ Creates the Management Zone
- ♦ Creates a password that you supply for the default ZENworks Administrator account

- ♦ Establishes and populates the ZENworks Configuration Management database

The ZENworks installation does the following during installation of any Primary Server:

- ♦ Installs the ZENworks Adaptive Agent (Windows servers only) so that it can be managed
- ♦ Installs ZENworks Control Center (ZCC)
- ♦ Installs the zman command line utility
- ♦ Installs and starts the ZENworks services
- ♦ (Optional) Installs BusinessObjects Enterprise XI Release 2 for custom ZENworks infrastructure reporting

The Adaptive Agent is installed to managed workstations from files on the Primary Server. For more information, see [“ZENworks Adaptive Agent Deployment”](#).

You have three installation methods:

- ♦ **Graphical User Interface:** A graphical user interface (GUI) installation program that works with both Windows and Linux servers is provided on the installation CD. For Linux servers, GUI capability must already be installed.
- ♦ **Command Line:** A command line installation is available, but only for Linux servers. The Windows and Linux installation executables can both be run from a command line for purposes of using installation arguments, but for Windows it only starts the GUI installation program.
- ♦ **Unattended:** You can use either installation method to create a response file for an unattended installation of ZENworks to other servers. For more information, see [Section 2.5, “Performing an Unattended Installation of ZENworks Configuration Management,”](#) on page 37.

To learn what you need to know before installing ZENworks, continue with [Section 2.2, “Gathering Information for Installing ZENworks,”](#) on page 18.

## 2.2 Gathering Information for Installing ZENworks

During installation of ZENworks Configuration Management, you need to know the following information:

- ♦ Which installation method to use (GUI, command line, or unattended)
- ♦ Installation path (for Windows only)
- ♦ Management Zone (zone name, username, password, and port)
- ♦ Database choice (embedded Sybase SQL, remote OEM Sybase SQL, external Sybase SQL, or external Microsoft SQL)

For more information, see [Section 2.3, “Preinstallation Tasks,”](#) on page 19.

- ♦ Database information (server name, port, database name, username, password, named instance, domain, and whether you are using Windows or SQL Server authentication)
- ♦ Certificate Authority information (internal, or signed certificate, private key, and public certificate) in DER format
- ♦ License keys (60-day trial options are available)

- ♦ Whether to install BusinessObjects Enterprise XI for custom ZENworks infrastructure reporting

If you plan to install BusinessObjects Enterprise XI, review the following information:

- ♦ BusinessObjects Enterprise XI can be installed automatically when installing Configuration Management to the server, or manually at a later time to any Primary Server.
- ♦ You can install BusinessObjects Enterprise XI to only one server in a Management Zone.
- ♦ You cannot run the BusinessObjects Enterprise XI installation from a network location.
- ♦ Reporting does not work if BusinessObjects Enterprise XI is installed on a Linux Primary server, and the ZENworks database is a Microsoft SQL 2005 Server database.
- ♦ Make sure that the network is up and running.

For more information on these items, see [Table 2-1, “Installation Information,” on page 27](#).

To start a ZENworks installation, continue with [Section 2.3, “Preinstallation Tasks,” on page 19](#).

## 2.3 Preinstallation Tasks

Perform the following applicable tasks, then continue with [Section 2.4, “Installing ZENworks Configuration Management,” on page 25](#):

- ♦ [Section 2.3.1, “Verifying That the Minimum Requirements Have Been Met,” on page 19](#)
- ♦ [Section 2.3.2, “Creating an Installation DVD from the ISO Download,” on page 19](#)
- ♦ [Section 2.3.3, “Creating External CAs,” on page 20](#)
- ♦ [Section 2.3.4, “Installing an External ZENworks Database,” on page 21](#)

### 2.3.1 Verifying That the Minimum Requirements Have Been Met

Make sure that the device where you want to install the Primary Server software fulfills the necessary requirements. For more information, see [Chapter 1, “Minimum Requirements,” on page 9](#).

If you plan to install BusinessObjects Enterprise XI:

- ♦ Make sure that ports 6400 and 3306 are free.
- ♦ Make sure that the server is connected to the network.

### 2.3.2 Creating an Installation DVD from the ISO Download

If you obtained the ZENworks Configuration Management software as an ISO image download, do one of the following to create the installation DVD:

- ♦ [“Using Windows to Create a ZENworks Installation DVD from an ISO Image” on page 20](#)
- ♦ [“Using Linux to Create a ZENworks Installation DVD from an ISO Image” on page 20](#)

## Using Windows to Create a ZENworks Installation DVD from an ISO Image

- 1 Download the ZENworks 10 Configuration Management installation ISO image from the [Novell Web site \(http://www.novell.com/\)](http://www.novell.com/) and copy it to a temporary location on your Windows device.
- 2 Burn the ISO image to a DVD.

## Using Linux to Create a ZENworks Installation DVD from an ISO Image

Optionally, you can simply run the installation program from the ISO mount point, instead of burning the DVD.

To create the DVD:

- 1 Download the ZENworks 10 Configuration Management installation ISO image from the [Novell Web site \(http://www.novell.com/\)](http://www.novell.com/) and copy it to a temporary location on your Linux device.
- 2 Mount the ISO image by using the following command:  

```
mount -o loop /tempfolderpath/isoimagename.iso mountpoint
```

Replace *tempfolderpath* with the path to the temporary folder, replace *isoimagename* with the ZENworks ISO filename, and replace *mountpoint* with the path to the file system location where you want to mount the image. The path specified by *mountpoint* must already exist.

For example:

```
mount -o loop /zcm10/ZCM10.iso /zcm10/install
```
- 3 Burn the ISO image to a DVD.

### 2.3.3 Creating External CAs

If you plan to use external CAs, do the following to create the certificate files:

- 1 To generate a private key that is needed to create a CSR, enter the following command:  

```
openssl genrsa -out zcm.pem 1024
```
- 2 To create a CSR that can be signed by the external CA, enter the following command:  

```
openssl req -new -key zcm.pem -out zcm.csr
```

When you are asked for “YOUR name,” enter the full DNS name assigned to the server where you are installing ZENworks Configuration Management.
- 3 To convert the private key from PEM format to DER format, enter the following command:  

```
openssl pkcs8 -topk8 -nocrypt -in zcm.pem -inform PEM -out zcm.der -outform DER
```

The private key must be in the PKCS8 DER format, and the signed certificate must be in the X.509 DER format. You can use the OpenSSL command line tool to convert your keys to the proper format. This tool can be obtained as part of the Cygwin toolkit, or as part of your Linux distribution.
- 4 Use the CSR and generate a certificate using ConsoleOne or a true external CA such as Verisign.
- 5 Using ConsoleOne, export your CA’s self-signed certificate.

- 6 To convert the signed certificate from PEM format to DER format, enter the following command:

```
openssl x509 -in cert.pem -inform PEM -out cert.der -outform DER
```

You should now have the three files that you need to install ZENworks using an external CA.

## 2.3.4 Installing an External ZENworks Database

During installation you have the following database options:

- ♦ Install to the embedded Sybase SQL Anywhere database that is provided by ZENworks
- ♦ Install to an existing remote OEM Sybase database
- ♦ Install to an existing Sybase SQL Anywhere external database
- ♦ Install to an existing Microsoft SQL Server external database
- ♦ Create a new Microsoft SQL Server external database

Some of these options require tasks related to creating or setting up external databases before ZENworks can write to them during installation. The steps in this section show how to do that.

If you want to use an remote OEM Sybase database, you must install it first so that it can be configured for ZENworks during installation of the Primary Server hosting the database. If the OEM Sybase server does not yet exist, you must create it first.

If you want to use an external Sybase SQL Anywhere database, you must set it up so that it can be updated during installation.

For the Microsoft SQL Server database, you have the option to create a new database during installation of Configuration Management. You can also create it before installing Configuration Management by using the steps in this section.

Make sure that the server where you plan to install the external database fulfills the requirements in [Section 1.2, “Database Requirements,” on page 12](#).

- 1 To start the database installation program:

- 1a On the installation server, insert the *Novell ZENworks 10 Configuration Management* DVD.

If the DVD autoruns the installation program, exit the program.

- 1b For Windows, enter the following at the command prompt:

```
DVD_drive:\setup.exe -c
```

- 1c For Linux, run the following command:

```
sh /media/cdrom/setup.sh -c
```

Using the `sh` command resolves rights issues.

Only the GUI installation is available for installing a database.

- 2 On the Select ZENworks Database page, select one of the following, then click *Next*.

- ♦ **OEM Sybase SQL Anywhere:** Installs the default Sybase 10 database for ZENworks. It is configured as a service, the database user is created, and the required tables for the Primary Server are established.

If you select this option, you must use the `-o` (or `--sybase-oem`) parameter with the `setup.exe` installation executable when you install the Primary Server software in

order to successfully install to the database. This parameter allows ZENworks to authenticate the database prior to performing any operations on it.

You should use the `-o` parameter only when you are using the Sybase installation that is provided on the *Novell ZENworks 10 Configuration Management* installation DVD.

You must also select the *Remote Sybase SQL Anywhere* option during installation of the Primary Server.

- ♦ **Sybase SQL Anywhere:** Sets up an existing Sybase database for writing ZENworks information to it.

The database user must have read/write permissions to create and modify the tables on the database server.

- ♦ **Microsoft SQL Server:** Creates a ZENworks database on a Microsoft SQL Server.

The Microsoft SQL Server software must already be installed on the database server in order for the Configuration Management installation program to create the new Microsoft SQL database. Refer to your Microsoft documentation for instructions on installing the Microsoft SQL Server software.

---

**IMPORTANT:** For external databases, the server hosting the database must have time synchronization with each of the Primary Servers in the Management Zone.

Reporting does not work if BusinessObjects Enterprise XI is installed on a Linux Primary server, and the ZENworks database is a Microsoft SQL 2005 Server database.

---

- 3 During installation, refer to the following information for details on the installation data that you need to know.

You can also click the *Help* button for similar information.

---

Installation Information	Explanation
Database paths	<p>For the <i>OEM Sybase SQL Anywhere</i> option, you need to provide the path to where you want the OEM copy of the Sybase SQL Anywhere database software installed. On the target Windows server, only the drives that are currently mapped on the server are available.</p> <p>The default path is <code>drive:\novell\zenworks</code>, which you can change. The installation program creates the <code>\novell\zenworks</code> directory for the installation of Sybase.</p> <p>You need to provide the path for where you want the ZENworks Sybase database file created. A <code>\database</code> directory is appended to the default of <code>drive:\novell\zenworks</code>.</p> <p>If you need more disk space for your content repository than is in the Windows path that is available during installation, you can change the path to another location after completing the installation. For more information, see “<a href="#">Content Repository</a>” in the <i>ZENworks 10 Configuration Management System Administration Reference</i>.</p>

---

Installation Information	Explanation
Database information	<p>For the two external database options (<i>Remote Sybase SQL Anywhere</i> and <i>Microsoft SQL Server</i>), you need to know the information listed below.</p> <p>Defaults are provided for some of this information, which can be changed as necessary.</p> <ul style="list-style-type: none"> <li>♦ <b>All Databases:</b> The database server must have a Sybase SQL Anywhere or Microsoft SQL database installed. <ul style="list-style-type: none"> <li>♦ Server's name. We recommend that you identify the server by its DNS name rather than its IP address, to be in sync with certificates that are signed using DNS names.</li> </ul> <hr/> <p><b>IMPORTANT:</b> If you later change your database server's IP address or DNS name, make sure that your corporate DNS server is updated with this change to keep DNS for the database server in sync.</p> <hr/> <li>♦ Port used by the database server.</li> </li></ul> <p>Port 2638 is the default for Sybase SQL Anywhere and port 1433 is the default for Microsoft SQL Server.</p> <p>Change the default port number if you have a conflict.</p> <ul style="list-style-type: none"> <li>♦ <b>(Optional) SQL Server Only:</b> Named instance, which is the name of the SQL server instance that is hosting the existing ZENworks Configuration Management database. You must specify the named instance if you want it to be something other than the default of <code>mssqlserver</code>.</li> <li>♦ <b>New Database:</b> <ul style="list-style-type: none"> <li>♦ The database administrator (<i>Username</i> field) must have read/write permissions in order to successfully perform the required operations on the database.</li> <li>♦ The administrator's database password.</li> </ul> </li> <li>♦ <b>SQL Server or New Database:</b> <ul style="list-style-type: none"> <li>♦ If you are using Windows authentication, specify the Windows domain where the user you specified in the <i>Username</i> field exists. If you are not using a Windows domain, specify the server's short name.</li> <li>♦ Whether to use Windows or SQL Server authentication. For Windows authentication, provide the credentials for a user on the current device or in the domain. For SQL authentication, provide credentials that match those of a valid SQL user.</li> </ul> </li> </ul> <p>It is important to know whether you installed the SQL Server by using SQL authentication, Windows authentication, or mixed. Be sure to select the option that coincides with your SQL Server options or the authentication will fail.</p> <hr/> <p><b>NOTE:</b> Reporting does not work if the ZENworks database is an SQL Server database, and the authentication mode is Windows Authentication. You must select the SQL Server authentication, and ensure that the SQL Server is configured to use the SQL Server Authentication mode.</p>

Installation Information	Explanation
Database access	<p>For the two external database options (<i>Remote Sybase SQL Anywhere</i> and <i>Microsoft SQL Server</i>), you need to know the information listed below.</p> <p>Defaults are provided for some of this information, which can be changed as necessary.</p> <ul style="list-style-type: none"> <li>♦ <b>All Databases:</b> This server must have a Sybase SQL Anywhere or Microsoft SQL database installed. <ul style="list-style-type: none"> <li>♦ Database name. Replace <i>zenworks_MY_ZONE</i> with either the desired database name, or an existing database name.</li> <li>♦ Database username. This user must have read/write permissions to modify the database. <p>If Windows authentication is also selected, the specified user must already exist when you create a new SQL database. The user is granted login access to SQL Server and read/write access to the ZENworks database that is created.</p> <p>For an existing database, specify a user with sufficient permissions to the database.</p> </li> <li>♦ Database password. For a new database, this password is automatically generated if SQL authentication is selected. For an existing database, specify the password of an existing user with read/write permissions to the database.</li> </ul> </li> <li>♦ <b>Sybase Databases Only:</b> The name of your Sybase SQL Anywhere database server.</li> <li>♦ <b>SQL Databases Only:</b> <ul style="list-style-type: none"> <li>♦ If you are using Windows authentication, specify the Windows domain where the user you specified in the <i>Username</i> field exists. If you are not using a Windows domain, specify the server's short name.</li> <li>♦ Whether to use Windows or SQL Server authentication. For Windows authentication, provide the credentials for a user on the current device or in the domain. For SQL authentication, provide credentials that match those of a valid SQL user.</li> </ul> </li> </ul> <p>It is important to know whether you installed the SQL Server by using SQL authentication, Windows authentication, or mixed. Be sure to select the option that coincides with your SQL Server options or the authentication will fail.</p>

4 Continue with [Section 2.4, “Installing ZENworks Configuration Management,” on page 25](#).



## 2.4 Installing ZENworks Configuration Management

To install Configuration Management:

- 1 Start the ZENworks Configuration Management installation program by using one of the following methods:

- ♦ **Graphical user interface (GUI) installation**

- a. On the installation server, insert the *Novell ZENworks 10 Configuration Management DVD*.

For Windows, the installation page where you can select the language is displayed. If it is not automatically displayed after inserting the DVD, run `setup.exe` from the root of the DVD.

For Linux, mount the DVD, then run `sh /media/cdrom/setup.sh`. Using the `sh` command resolves rights issues.

- b. If you installed an external OEM Sybase server (see [Section 2.3.4, “Installing an External ZENworks Database,” on page 21](#)), you must run the executable manually with the following parameter in order for that database to be properly updated during this Primary Server installation:

```
DVD_drive\setup.exe -o
```

- c. Continue with [Step 2](#).

- ♦ **Command line installation (Linux only)**

- a. On the installation server, insert the *Novell ZENworks 10 Configuration Management DVD*.

- b. Mount the DVD.

- c. To start a command line installation, do the following:

- i. To a directory where all (including “others”) have read and execute access, either mount the DVD or copy the DVD’s files.

This cannot be in `/root` or any directory under it.

If you copy the DVD’s files, make sure that all (including “others”) continue to have read and execute access to the destination directories.

- ii. Run the following command:

```
/mount_location/setup.sh -e
```

For more information on installation arguments, see [Appendix A, “Installation Executable Arguments,” on page 43](#).

- d. Continue with [Step 2](#).

- ♦ **Silent Installation**

To install using a response file, see [Section 2.5, “Performing an Unattended Installation of ZENworks Configuration Management,” on page 37](#).

- 2 During installation, refer to the information in [Table 2-1, “Installation Information,” on page 27](#) for details on the installation data that you need to know.

If you are using the GUI installation, you can also click the *Help* button for similar information.

For the command line method, you can type `back` and press Enter to return to a previous installation option to make changes.

**3** Do one of the following:

- ♦ If you selected to reboot manually (you selected the *No, I will restart the system myself* option during installation; see “**Rebooting (or not)**” on page 34), you must reboot to complete the installation in order to verify it in **Step 4**.
- ♦ If you selected to reboot automatically (you selected the *Yes, restart the system* option during installation; see “**Rebooting (or not)**” on page 34), continue with **Step 4** after the booting process has completed.

The first time you reboot after installing, the process can take awhile because the database is being updated.

**4** After the installation has completed and the server has been rebooted, do any of the following to verify that ZENworks Configuration Management is running:

♦ **Run ZCC**

If ZCC did not automatically start, use the following URL to open ZCC in a Web browser:

`https://DNS_name_or_IP_address_of_Primary_Server/zenworks`

This can be done either on the server where you just installed ZENworks, or on a **qualified workstation**.

---

**IMPORTANT:** If you installed BusinessObjects XI, click the *Reports* tab, then click *Predefined Reports* to ensure that it is working.

If the installation was unsuccessful, the following might be displayed at the top of the ZCC page for the *Reports* tab:

There are no Business Objects Reporting servers configured in the Management Zone.

If this is displayed, you need to manually install BusinessObjects XI. For instructions, see **Section 2.4.2, “Manually Installing BusinessObjects Enterprise XI,” on page 35**.

---

♦ **Check the Windows services by using the GUI**

On the server, click *Start*, select *Administrative Tools > Services*, then review the status of the *Novell ZENworks Loader* and *Novell ZENworks Server* services.

If they are not running, start the ZENworks services. Right-click the *Novell ZENworks Server* service, select *Start*, right-click the *Novell ZENworks Loader* service, then select *Start*.

The *Restart* option stops all related services that are already running and starts each of them in their correct order, including *Novell ZENworks Loader*.

♦ **Check the Linux services by using the configuration command**

On the server, run the following command:

```
/opt/novell/zenworks/bin/novell-zenworks-configure  
-c SystemStatus
```

This lists all ZENworks services and their statuses.

To start the services, run the following command:

```
/opt/novell/zenworks/bin/novell-zenworks-configure -c Start
```

- ♦ **Check the Linux services by using the specific services' commands**

On the server, run the following commands:

```
/etc/init.d/novell-zenserver status
```

```
/etc/init.d/novell-zenloader status
```

If the services are not running, run the following commands to start the ZENworks services:

```
/etc/init.d/novell-zenserver start
```

```
/etc/init.d/novell-zenloader start
```

**5** Do any of the following that are applicable, then continue with **Step 6**:

- ♦ To create another Primary Server for the Management Zone using the same installation method that you just used, return to **Step 1**.
- ♦ If you created a **response file** in order to perform an unattended installation on other servers, continue with **Section 2.5.2, “Performing an Unattended Installation,”** on page 39.

**6** Continue with the ***ZENworks 10 Configuration Management Administration Quick Start*** for concepts and high-level instructions on how to further set up and use Configuration Management.

## 2.4.1 Installation Information

The information you need is listed in the order of the installation flow.

**Table 2-1** *Installation Information*

Installation Information	Explanation
Installation path (Windows only)	<p>The default is %ProgramFiles%. You can change it to any path currently available on the server. The installation program creates the Novell\ZENworks directory here for the installation of the ZENworks software files.</p> <p>If you need more disk space for your content repository than is in the Windows path that is available during installation, you can change the path to another location after completing the installation. For more information, see “<b>Content Repository</b>”.</p> <p>For Linux, several fixed installation paths are used:</p> <pre>/opt/novell/zenworks/ /etc/opt/novell/zenworks /var/opt/novell/zenworks /var/opt/novell/log/zenworks/</pre> <p>If you are concerned about disk space on the Linux server, the /opt directory is where the database and content repository reside. Make sure it is on a partition large enough for them.</p>

Installation Information	Explanation
Response file path (optional)	<p>If you started the installation executable with the <code>-s</code> parameter, you are required to provide a path for the file. The default path is <code>C:\Documents and Settings\Administrator\</code>, which you can change to any path available on the current server.</p> <p>The Primary Server software is not installed when you run the program to create a response file. It only displays the installation pages necessary to identify and create the response file.</p>
Prerequisites	<p>If the required prerequisites are not installed, you are not allowed to continue with the installation. The requirements that are not fulfilled are displayed (GUI) or listed (command line). For more information, see <a href="#">Section 1.1, "Primary Server Requirements," on page 9</a>.</p> <p>If the .NET prerequisite is not fulfilled, you can click the <i>ZENworks</i> link in the description to install the runtime version that is bundled with ZENworks. After .NET is installed, the installation of ZENworks proceeds from where you left off.</p>
Management Zone	<p><b>New Zone:</b> If you are installing to the first server in the zone, you need to know what name you want for the Management Zone and what you want to use for the zone's password, which is used for logging in to ZCC.</p> <p>The zone name has a 20-character limit and should be a unique name.</p> <p>By default, the login username is <code>administrator</code>. After completing the installation, you can use ZCC to add other administrator names that can be used to log in to the Management Zone.</p> <p>If one or both of the default Configuration Management ports for ZCC is in use (HTTP = 80 or HTTPS = 443), such as by OES2, you will be asked to specify another port. Note which port you specify because you will need to use it in the URL for accessing ZCC.</p> <p><b>Existing Zone:</b> If you are installing to an existing Management Zone, you need to know the following information:</p> <ul style="list-style-type: none"> <li>♦ Server identification (either the DNS name or IP address). This is any existing Primary Server in the zone. We recommend using the DNS name to provide ongoing synchronization with certificates that are signed with DNS names.</li> <li>♦ Port used by the existing Primary Server in the Management Zone. If this Primary Server uses a different port than the default (443), specify that server's port.</li> <li>♦ <i>Use SSL</i> check box: Specify whether the port you specified is secured.</li> <li>♦ The username for logging in to ZCC. The default is <code>administrator</code>. After completing the installation, you can use ZCC to add other administrator names that can be used to log in to the Management Zone.</li> <li>♦ The administrator's password. Specify the current password for the ZENworks administrative user specified in the <i>Username</i> field.</li> </ul> <p><b>BusinessObjects option:</b> For either zone option (new or existing), you have the option to install BusinessObjects Enterprise XI for ZENworks infrastructure reporting. However, you can also <a href="#">install BusinessObjects XI manually</a> at a later time. The installation of the BusinessObjects XI files can take awhile.</p>

Installation Information	Explanation
Database options	<p>For ZENworks Configuration Management, a database must be established. The database options are displayed only when the first server is installed to the zone. However, you can run the installation program specifically to install or repair a database (see <a href="#">Section 2.3.4, “Installing an External ZENworks Database,” on page 21</a>).</p> <p>You have the following three database options:</p> <ul style="list-style-type: none"> <li>♦ <b>Embedded Sybase SQL Anywhere:</b> Automatically installs the embedded database on the current server.  If you select the embedded database option, no further database installation pages are shown.</li> <li>♦ <b>Remote Sybase SQL Anywhere:</b> This database must already exist on a server in your network. It can be on the current server.  To select this option, you should already have followed the steps in <a href="#">Section 2.3.4, “Installing an External ZENworks Database,” on page 21</a>.</li> <li>♦ <b>Microsoft SQL Server:</b> You can create a new SQL database or specify an existing database that resides on a server in your network. It can be on the current server.</li> </ul> <hr/> <p><b>IMPORTANT:</b> Reporting does not work if BusinessObjects Enterprise XI is installed on a Linux Primary server, and the ZENworks database is a Microsoft SQL 2005 Server database.</p> <hr/> <p>Creating a new SQL database at this time provides the same results as the steps in <a href="#">Section 2.3.4, “Installing an External ZENworks Database,” on page 21</a>.</p> <hr/> <p><b>IMPORTANT:</b> For external databases, the server hosting the database must have time synchronization with each of the Primary Servers in the Management Zone.</p>

Installation Information	Explanation
Database information	<p>For the external database options (<i>Remote Sybase SQL Anywhere</i> and <i>Microsoft SQL Server</i>), you need to know the information listed below. Defaults are provided for some of this information, which can be changed as necessary.</p> <ul style="list-style-type: none"> <li>♦ <b>All Databases:</b> The database server must have a Sybase SQL Anywhere or Microsoft SQL database installed. <ul style="list-style-type: none"> <li>♦ Server's name. We recommend that you identify the server by its DNS name rather than its IP address, to be in sync with certificates that are signed with DNS names.</li> </ul> <hr/> <p><b>IMPORTANT:</b> If you later change your database server's IP address or DNS name, make sure that your corporate DNS server is updated with this change to keep DNS for the database server in syn.</p> <hr/> <ul style="list-style-type: none"> <li>♦ Port used by the database server.</li> </ul> <p>Port 2638 is the default for Sybase SQL Anywhere and port 1433 is the default for Microsoft SQL Server.</p> <p>Change the default port number if you have a conflict.</p> </li> <li>♦ <b>(Optional) SQL Server Only:</b> Named instance, which is the name of the SQL server instance that is hosting the existing ZENworks Configuration Management database. You must specify the named instance if you want it to be something other than the default of <code>mssqlserver</code>.</li> <li>♦ <b>New Database:</b> <ul style="list-style-type: none"> <li>♦ The database administrator (<i>Username</i> field) must have read/write permissions in order to successfully perform the required operations on the database.</li> <li>♦ The administrator's database password.</li> </ul> </li> <li>♦ <b>SQL Server or New Database:</b> <ul style="list-style-type: none"> <li>♦ If you are using Windows authentication, specify the Windows domain where the user you specified in the <i>Username</i> field exists. If you are not using a Windows domain, specify the server's short name.</li> <li>♦ Whether to use Windows or SQL Server authentication. For Windows authentication, provide the credentials for a user on the current device or in the domain. For SQL authentication, provide credentials that match those of a valid SQL user.</li> </ul> </li> </ul> <p>It is important to know whether you installed the SQL Server by using SQL authentication, Windows authentication, or mixed. Be sure to select the option that coincides with your SQL Server options or the authentication will fail.</p> <hr/> <p><b>NOTE:</b> Reporting does not work if the ZENworks database is an SQL Server database, and the authentication mode is Windows Authentication. You must select the SQL Server authentication, and ensure that the SQL Server is configured to use the SQL Server Authentication mode.</p>

Installation Information	Explanation
Database access	<p>For the two external database options (<i>Remote Sybase SQL Anywhere</i> and <i>Microsoft SQL Server</i>), you need to know the information listed below. Defaults are provided for some of this information, which can be changed as necessary.</p> <ul style="list-style-type: none"> <li>♦ <b>All Databases:</b> This server must have a Sybase SQL Anywhere or Microsoft SQL database installed. <ul style="list-style-type: none"> <li>♦ Database name. Replace <i>zenworks_MY_ZONE</i> with either the desired database name, or an existing database name.</li> <li>♦ Database username. This user must have read/write permissions to modify the database. <p>If Windows authentication is also selected, the specified user must already exist when you create a new SQL database. The user is granted login access to SQL Server and read/write access to the ZENworks database that is created.</p> <p>For an existing database, specify a user with sufficient permissions to the database.</p> </li> <li>♦ Database password. For a new database, this password is automatically generated if SQL authentication is selected. For an existing database, specify the password of an existing user with read/write permissions to the database.</li> </ul> </li> <li>♦ <b>Sybase Databases Only:</b> The name of your Sybase SQL Anywhere database server.</li> <li>♦ <b>SQL Databases Only:</b> <ul style="list-style-type: none"> <li>♦ If you are using Windows authentication, specify the Windows domain where the user you specified in the <i>Username</i> field exists. If you are not using a Windows domain, specify the server's short name.</li> <li>♦ Whether to use Windows or SQL Server authentication. For Windows authentication, provide the credentials for a user on the current device or in the domain. For SQL authentication, provide credentials that match those of a valid SQL user.</li> </ul> <p>It is important to know whether you installed the SQL Server by using SQL authentication, Windows authentication, or mixed. Be sure to select the option that coincides with your SQL Server options or the authentication will fail.</p> </li> </ul>
SSL configuration (shown only for first server installed in the Management Zone)	<p>In order to enable SSL communications, an SSL certificate must be added to the ZENworks server. Select whether to use an internal or external certificate authority (CA).</p> <p>For subsequent installations of Primary Servers to the Management Zone, the CA established by the first server's installation is used for the zone.</p> <hr/> <p><b>IMPORTANT:</b> After you install ZENworks Configuration Management, you cannot change the CA type.</p> <hr/> <p>The <i>Restore Default</i> buttons restore the paths to those that were displayed when you first accessed this page.</p>

Installation Information	Explanation
Signed SSL certificate and private key	<p>To enter a trusted CA-signed certificate and private key, click <i>Choose</i> to browse for and select the certificate and key files, or specify paths to the signed certificate to be used for this server (<i>Signed SSL Certificate</i>), and the private key associated with the signed certificate (<i>Private Key</i>).</p> <p>For subsequent installations of Primary Servers to the zone, the CA established for the zone by the first server's installation is used.</p> <p>For information on creating external certificates to select when installing to a Linux or Windows server, see <a href="#">Section 2.3.3, "Creating External CAs," on page 20</a>.</p> <p>For information on creating external certificates for installing to a Linux server using a silent installation, see <a href="#">Step 4 in Section 2.5.1, "Creating Your Response File," on page 37</a>.</p>
Root certificate (optional)	To enter a trusted CA root certificate, click <i>Choose</i> to browse for and select it, or specify the path to the CA's public X.509 certificate ( <i>CA Root Certificate</i> ).
License key	Specify the license key that you obtained when you purchased the product, or leave the field blank to use the 60-day trial license.
Pre-installation summary	<p><b>GUI Installation:</b> To make changes to any information entered up to this point, click <i>Previous</i>. After you click <i>Install</i>, the installation of the files begins. During installation, you can click <i>Cancel</i> to stop, which leaves the files on your server that were installed up to that point.</p> <p><b>Command Line Installation:</b> If you want to make changes to any information entered up to this point, you can type <i>back</i> and press Enter as many times as necessary. As you progress forward through the commands again, press Enter to accept the decisions that you previously made.</p> <p><b>Installation Recovery:</b> For both the GUI and command line installations, if there are serious installation errors you can roll back the installation to return your server to its previous state. This option is provided on a different installation page. Otherwise, you have two options:</p> <ul style="list-style-type: none"> <li>♦ If a previous installation was cut short and you install again, you might be given the option to reset the installation, depending on how far you got in the canceled installation. If you select to reset, this overwrites any configuration that might have occurred during the canceled installation.</li> <li>♦ To undo a successfully completed installation, follow the instructions in <a href="#">Chapter 3, "Uninstalling Configuration Management," on page 41</a>.</li> </ul>
Installation complete (roll back option)	<p>If installation errors occurred, this page is displayed at this time; otherwise, it is displayed after the Post-Installation Actions page.</p> <p>If there were serious installation errors, select <i>Roll Back</i>, which returns your server to its previous state. Upon exiting the installation program, the server is not rebooted. However, to complete the installation, you must reboot the server so that the ZENworks database can be populated with the inventory data.</p> <p>To determine whether to continue the installation or roll it back, review the log file that lists the errors to determine if any installation failures were significant enough for your action. If you select to continue, resolve the issues that are noted in the log after you have rebooted the server and completed the installation process.</p> <p>To access the log file in the GUI installation, click <i>View Log</i>. In the command line installation, the path to the log file is displayed.</p>



Installation Information	Explanation
Post installation actions	<p>Options are presented for selecting actions to perform after installation of the software files has successfully completed:</p> <ul style="list-style-type: none"> <li>♦ For the GUI installation, a page displays the options listed below. Some items are selected by default. Click any check box to select or deselect the option, then click <i>Next</i> to continue.</li> <li>♦ For a command line installation, the options are listed with option numbers. Select or deselect an option by typing its number to toggle its selection status. After configuring the selections, press Enter without typing a number to continue.</li> </ul> <p>Select from the following possible actions:</p> <ul style="list-style-type: none"> <li>♦ <b>Run ZENworks System Status Utility:</b> Launches a ZENworks services heartbeat check prior to closing the installation program. Results are posted in the installation log.</li> <li>♦ <b>Run ZENworks Control Center:</b> (GUI installation only) Automatically opens ZCC in your default Web browser after rebooting (Windows only), or immediately if you select to reboot manually or you installed to a Linux server. For a Linux installation without a GUI, a GUI-enabled device must be used to run ZCC.</li> <li>♦ <b>Place a shortcut to ZENworks Control Center on the Desktop:</b> (Windows only) Places the shortcut on your desktop.</li> <li>♦ <b>Place a shortcut to ZENworks Control Center in the Start Menu:</b> (Windows only) Places the shortcut in your Start menu.</li> <li>♦ <b>View Readme file:</b> For GUI installations, opens the ZENworks Configuration Management Readme in your default browser after rebooting (Windows only), or immediately if you select to reboot manually or you installed to a Linux server. For a Linux command line installation, the URL to the Readme is listed.</li> <li>♦ <b>View Installation log:</b> Displays the installation log in your default XML viewer (GUI installation) after rebooting, or immediately if you select to reboot manually. For a Linux command line installation, the information is simply listed.</li> <li>♦ <b>Install Add-On: BusinessObjects Enterprise XI:</b> Installs BusinessObjects XI for custom ZENworks infrastructure reporting.</li> </ul> <p>If you receive a warning on port conflicts, you must free ports 6400 and 3306, then continue with the installation by entering the appropriate default port. 6400 is the default Central Management Server port and 3306 is the default Service port.</p> <p>Installation of the BusinessObjects XI files can take awhile.</p> <hr/> <p><b>IMPORTANT:</b> If you want to install BusinessObjects XI at a later time, follow the instructions in <a href="#">Section 2.4.2, "Manually Installing BusinessObjects Enterprise XI," on page 35</a> when you are ready to install it.</p>

Installation Information	Explanation
Rebooting (or not)	<p>Upon a successful installation, you can select between rebooting immediately or later:</p> <ul style="list-style-type: none"> <li>♦ <b>Yes, Restart the System:</b> If you select this option, log in to the server when prompted. The first time you log in to the server, it takes a few minutes because the database is being populated with inventory data.</li> <li>♦ <b>No, I Will Restart the System Myself:</b> If you select this option, the next time you reboot the server, it takes a few minutes because the database is being populated with inventory data.</li> </ul> <p>You must eventually reboot the server in order to use Configuration Management.</p> <p>The process of populating the database can cause high CPU utilization during that time.</p> <p>The Patch Management downloads can also cause high CPU utilization, usually shortly after rebooting.</p>
Installation completion	<p>The actions you selected previously are performed after all of the files have been installed for Configuration Management and BusinessObjects XI (if selected). These include:</p> <ul style="list-style-type: none"> <li>♦ (Windows only) Creating the ZENworks Adaptive Agent icon in the notification area (system tray)</li> <li>♦ (Windows only) Creating the ZCC icon on the desktop or Start menu</li> <li>♦ Displaying the Readme</li> <li>♦ Displaying the installation log file</li> <li>♦ Opening ZCC</li> </ul> <p>To install BusinessObjects XI manually, follow the instructions in <a href="#">Section 2.4.2, "Manually Installing BusinessObjects Enterprise XI," on page 35.</a></p> <hr/> <p><b>IMPORTANT:</b> If you installed to a Linux server using the command line, and if you plan to run any zman commands in the current session, you need to get the newly installed <code>/opt/novell/zenworks/bin</code> directory into your session's path. Log out of your session and log back in to reset the PATH variable.</p>

## 2.4.2 Manually Installing BusinessObjects Enterprise XI

If you need to manually install BusinessObjects XI on an existing Windows Primary Server, do one of the following:

- ♦ “GUI Installation” on page 35
- ♦ “Command Line Installation” on page 35

If you need to manually install BusinessObjects XI manually on an existing Linux Primary Server, use “Command Line Installation” on page 35.

### GUI Installation

You can use the GUI installation mode only to manually install BusinessObjects XI on an existing Windows Primary Server.

- 1 Select the Primary Server where you want to install BusinessObjects XI and make sure that you have fulfilled the **RAM and disk space requirements** for installing BusinessObjects XI.

Specifically, you need an additional 512 MB of RAM (1 GB additional is recommended) and at least 3 GB of free disk space for the BusinessObjects XI files.

- 2 Make sure that ports 6400 and 3306 are free.
- 3 On this server, run `DVD_drive:\setup.exe -b`.

This executable is found at the root of the *Novell ZENworks 10 Configuration Management* DVD.

The command does not work if ZENworks Configuration Management is not installed on the server.

- 4 Specify the path to the BusinessObjects XI executable on the DVD.

By default, the path is `DVD_drive:\novell\zenworks\boe\windows\setup.exe`.

- 5 After the installation has completed, restart the server.

Installation of the BusinessObjects XI files can take awhile, even after the installation progress bar disappears.

- 6 To verify that the installation completed successfully, open ZENworks Control Center, click the *Reports* tab, then click *Predefined Reports*.

If the installation was successful, the Predefined Reports page should be displayed.

If the installation was unsuccessful, the following might be displayed at the top of the ZCC page for the *Reports* tab:

There are no Business Objects Reporting servers configured in the Management Zone.

For more information, review the BusinessObjects XI installation log file,  
`Installation_path\Novell\ZENworks\share\boe\BusinessObjectsEnterprise11.5\Logging\BOEInstall_0.log`

### Command Line Installation

You can use the Command Line installation mode to manually install BusinessObjects XI on an existing Linux or Windows Primary Server.

- 1 Select the Primary Server where you want to install BusinessObjects XI and make sure that you have fulfilled the **RAM and disk space requirements** for installing BusinessObjects XI.

Specifically, you need an additional 512 MB of RAM (1 GB additional is recommended) and at least 3 GB of free disk space for the BusinessObjects XI files.

- 2 Make sure that ports 6400 and 3306 are free.
- 3 Run the following command on the target Primary Server:

```
ZENworks_installation_path\novell\zenworks\bin\novell-zenworks-configure.bat -c InstallBOE
```

If you change to the `\novell\zenworks\bin` directory to run `novell-zenworks-configure`, you need to provide a relative path to the executable in **Step 5**.

- 4 Type 1 and press Enter to select *Yes* to install BusinessObjects XI, then press Enter again to continue.
- 5 Specify the path to the BusinessObjects XI executable on the DVD. For example:  

```
DVD_drive:\novell\zenworks\boe\windows\setup.exe
```
- 6 If you receive a warning on port conflicts, you must free ports 6400 and 3306, then continue with the installation by entering the appropriate default port. 6400 is the default Central Management Server port and 3306 is the default Service port.
- 7 Follow the installation prompts.

Installation of the BusinessObjects XI files can take awhile, even after the installation progress bar disappears.

- 8 After the installation has completed, restart the server.
- 9 To verify that the installation completed successfully, open ZENworks Control Center, click the *Reports* tab, then click *Predefined Reports*.

If the installation was successful, the Predefined Reports page should be displayed.

If the installation was unsuccessful, the following might be displayed at the top of the ZCC page for the *Reports* tab:

There are no Business Objects Reporting servers configured in the Management Zone.

For more information, review the BusinessObjects XI installation log file.

- ♦ **On a Windows server:** `Installation_path\Novell\ZENworks\share\boe\BusinessObjectsEnterprise11.5\Logging\BOEInstall_0.log`
- ♦ **On a Linux server:** `/var/opt/novell/log/zenworks/install_boe.log`

## 2.5 Performing an Unattended Installation of ZENworks Configuration Management

You can use a response file to perform an unattended installation of ZENworks Configuration Management. You can either edit the default response file (provided at `DVD_drive:\Disk1\InstData\silentinstall.properties`), or perform an installation to create your own version of the response file that contains the basic installation information and edit that copy as needed.

Do the following to create the response file, then use it to perform an unattended installation:

- ♦ [Section 2.5.1, “Creating Your Response File,” on page 37](#)
- ♦ [Section 2.5.2, “Performing an Unattended Installation,” on page 39](#)

### 2.5.1 Creating Your Response File

- 1 Run the ZENworks Configuration Management executable on a server by using one of the following methods:

- ♦ **Windows GUI**

```
DVD_drive:\setup.exe -s
```

- ♦ **Linux GUI**

```
sh /media/cdrom/setup.sh -s
```

Using the `sh` command resolves rights issues.

- ♦ **Linux command line**

```
sh /media/cdrom/setup.sh -e -s
```

For more information on the installation arguments, see [Appendix A, “Installation Executable Arguments,” on page 43](#).

- 2 When prompted, provide a path for your custom response file.

When you use the `-s` argument by itself, the installation program prompts you for a path for the response file. The default filename is `silentinstall.properties`, which you can rename later (see [Step 3e](#)). The default response file is modified by the installation program to create your custom response file.

- 3 Add the Management Zone password to your custom response file.

Because the Management Zone password that you enter during installation is not saved in the response file, you must add the password in each copy of the response file in order for it to be correctly provided during an unattended installation.

Optionally, you can create an environment variable to pass the password into the unattended installation. Instructions for this are contained in the response file where the password information is stored.

While you are editing the response file, you can make any other changes necessary to customize it for your unattended installation. The response file contains instructions for its various sections.

To add the Management Zone password into the response file:

**3a** Open the response file in a text editor.

Your custom response file is located where you specified in **Step 2**.

If you are editing the default response file, it is located at

`DVD_drive:\Disk1\InstData\silentinstall.properties`.

**3b** Search for `ADMINISTRATOR_PASSWORD=`.

**3c** Replace `$DOLLAR$lax.nl.env.ADMIN_PASSWORD$DOLLAR$` with the actual password.

**3d** Save the file and exit the editor.

**3e** Make as many differently named copies as you need for your various installation scenarios, modify each copy as necessary, then copy each one to the server where it will be used.

You must retain the `.properties` filename extension when renaming your copies.

**4** If you plan to use this response file to perform a silent installation to an Open Enterprise Server 2 (OES Linux) server, insert the following into the file:

```
PRIMARY_SERVER_ADDRESS=123.456.78.9
PRIMARY_SERVER_PORT=443
PRIMARY_SERVER_USE_SSL=true
PRIMARY_SERVER_CERT=-----BEGIN CERTIFICATE-----
MIID9DCCLotsOfEncryptedCharactersSja+bY05Y=-----END CERTIFICATE---
--
```

where `PRIMARY_SERVER_CERT=` is the certificate you specified in the first Primary Server that you installed to. The above is just an example of the certificate information.

Optionally, you can set the `PRIMARY_SERVER_USE_SSL=` variable to false:

```
PRIMARY_SERVER_USE_SSL=false
```

This allows you to do a clear text installation so that you do not need to specify the Primary Server's certificate.

**5** After you have completed modifications to your custom response file, copy it from the path that you specified in **Step 2** to a location on each server where you will use it for the unattended installation.

**6** To use the updated response file, continue with **Section 2.5.2, "Performing an Unattended Installation,"** on page 39.

## 2.5.2 Performing an Unattended Installation

- 1 On the installation server where you will perform an unattended installation, insert the *Novell ZENworks 10 Configuration Management* DVD.
  - ♦ For Windows, if the installation page where you can select the language is displayed, click *Cancel* to exit the GUI installation.
  - ♦ For Linux, mount the installation DVD.
- 2 To start the unattended installation, use the `-f` option in the command:
  - ♦ For Windows, run `DVD_drive:\setup.exe -s -f path_to_file`.
  - ♦ For Linux, run `sh /media/cdrom/setup.sh -s -f path_to_file`.

where `path_to_file` is either the full path to the response file that you created in [Section 2.5.1, “Creating Your Response File,” on page 37](#), or a directory containing the `silentinstall.properties` file (it must use that filename).

Using the `sh` command resolves rights issues.

If you renamed the updated response file, include its new name with the path.

If a filename is not given, or if either the path or file does not exist, the `-f` parameter is ignored and the default installation (GUI or command line) is run instead of an unattended installation.

- 3 Reboot the server after the silent installation has completed.

Rebooting is not automatically done after performing a silent installation. You must reboot the server for the installation to be completed.

A silent installation does not provide an installation progress bar.

- 4 After the installation has completed and the server has been rebooted, do any of the following to verify that ZENworks Configuration Management is running:

- ♦ **Run ZCC**

If ZCC did not automatically start, use the following URL to open ZCC in a Web browser:

`https://DNS_name_or_IP_address_of_Primary_Server/zenworks`

This can be done either on the server where you just installed ZENworks, or on a [qualified workstation](#).

- ♦ **Check the Windows services by using the GUI**

On the server, click *Start*, select *Administrative Tools > Services*, then review the status of the *Novell ZENworks Loader* and *Novell ZENworks Server* services.

If they are not running, start the ZENworks services. Right-click the *Novell ZENworks Server* service, select *Start*, right-click the *Novell ZENworks Loader* service, then select *Start*.

The *Restart* option stops all related services that are already running and starts each of them in their correct order, including *Novell ZENworks Loader*.

- ♦ **Check the Windows services by using a command line**

On the server, click *Start*, click *Run*, then run the following command:

```
ZENworks_installation_path\bin\novell-zenworks-configure  
-c SystemStatus
```

This lists all ZENworks services and their statuses.

To start the services, run the following command:

```
ZENworks_installation_path\bin\novell-zenworks-configure  
-c Start
```

- ♦ **Check the Linux services by using the configuration command**

On the server, run the following command:

```
/opt/novell/zenworks/bin/novell-zenworks-configure  
-c SystemStatus
```

This lists all ZENworks services and their statuses.

To start the services, run the following command:

```
/opt/novell/zenworks/bin/novell-zenworks-configure -c Start
```

- ♦ **Check the Linux services by using the specific services' commands**

On the server, run the following commands:

```
/etc/init.d/novell-zenserver status  
/etc/init.d/novell-zenloader status
```

If the services are not running, run the following commands to start the ZENworks services:

```
/etc/init.d/novell-zenserver start  
/etc/init.d/novell-zenloader start
```

- 5 To create another Primary Server for the Management Zone by performing an unattended installation, return to **Step 1**; otherwise, continue with **Step 6**.
- 6 After the installation has completed, continue with the *ZENworks 10 Configuration Management Administration Quick Start* for concepts and high-level instructions on how to further set up and use Configuration Management.



# Uninstalling Configuration Management

# 3

You can uninstall Novell® ZENworks® 10 Configuration Management from a Primary Server, or uninstall the ZENworks Adaptive Agent from a managed device.

You cannot separately uninstall BusinessObjects Enterprise XI. To uninstall BusinessObjects Enterprise, you must uninstall ZENworks Configuration Management.

To uninstall an external ZENworks database, see the instructions provided by the database manufacturer. The embedded ZENworks database can only be uninstalled by uninstalling Configuration Management from the device hosting the Management Zone.

---

**WARNING:** If you uninstall on the first Primary Server where you installed an embedded ZENworks Configuration Management database and established the Management Zone, all other Primary Servers in the Management Zone are orphaned because the Management Zone and database are no longer available. Therefore, to completely remove Configuration Management from your network, we recommend that you uninstall Configuration Management in the reverse order that you installed it. For example, 1) uninstall the Adaptive Agent from each managed device, 2) uninstall the other Primary Servers, then 3) uninstall the Primary Server hosting the Management Zone.

---

To uninstall Novell ZENworks Configuration Management:

**1** On the server or managed device, do the following:

- ♦ For Windows, run:

```
install_location\novell\zenworks\bin\zenworksuninstall.exe
```

- ♦ For Linux, run:

```
mono /opt/novell/zenworks/bin/ZENworksUninstall.exe
```

**2** Refer to the information in the following table during uninstallation.

The information is listed in the order of the uninstallation flow.

Information	Explanation
Administrator Information	Specify the Management Zone password.

Information	Explanation
Uninstallation Options	<p>Select an option:</p> <ul style="list-style-type: none"> <li>♦ <b>Remove Device from Zone:</b> Uninstalls ZENworks from the device and removes it from the Management Zone.</li> </ul> <hr/> <p><b>WARNING:</b> If this device hosts the Management Zone, this also removes the zone.</p> <hr/> <ul style="list-style-type: none"> <li>♦ <b>Local Uninstallation Only:</b> Only uninstalls ZENworks from the device. It continues to be registered in the Management Zone.</li> </ul> <p>This is useful if you don't have a connection with the Management Zone when you want to remove ZENworks from the device, or if the device's ZENworks installation is corrupted and needs to be reinstalled.</p>
Leave Files	<p>Select an option:</p> <ul style="list-style-type: none"> <li>♦ <b>ZENworks Agent:</b> Leaves the ZENworks Adaptive Agent installed on the device, but removes all other ZENworks Configuration Management software. By default, this is not selected.</li> <li>♦ <b>CASA:</b> Leaves the CASA software installed. By default, this is selected because CASA can be used by other software programs.</li> </ul>
Restart?	<p>By default, the <i>Restart Now</i> option is selected.</p> <p>Restarting completes the uninstallation process. Some files are not deleted until the device is restarted.</p>

**3** Click *Finish* to complete the installation.

If you selected *Restart Now*, the device is rebooted to complete the installation. If not, the uninstallation is not complete until you reboot.

**4** If there are any files in the following locations after the device has rebooted, you can delete them manually:

- ♦ **CASA:** If you are not using CASA for other programs, you can delete this directory.
- ♦ **ZENworks:** Log files are purposely left here for your review. You can manually delete the ZENworks directory at any time.

**5** For Windows, if the ZCC icon remains on the desktop, you can manually delete it.

# Installation Executable Arguments

# A

To install Novell® ZENworks® 10 Configuration Management, the following arguments can be used with the `setup.exe` and `setup.sh` executable files that are located at the root of the installation DVD. You can run these files from a command line.

You should use the `sh` command with `setup.sh` in order to prevent rights issues.

**Table A-1** *Installation Executable Arguments*

Argument	Long Form	Explanation
-e	--console	(Linux only) Forces a command line installation.
-l	--database-location	Specifies a custom OEM (embedded) database directory.
-c	--create-db	Launches a database administration tool.  It cannot be used at the same time as the -o argument.
-o	--sysbase-oem	Authenticates to an OEM database that is not set up by the installation program. This causes the installation program to present you with only the necessary database options for an external database, instead of the usual database options.  It cannot be used at the same time as the -c argument.
-s	--silent	If this is not used with the -f argument, it causes the installation that you are performing to create a response file (with a <code>.properties</code> filename extension) that you can edit, rename, and use for an unattended installation to another server.  If this is used with the -f argument, an unattended installation on the server is started, using the response file that you specify with the -f argument.
-f [path to file]	--property-file [path to file]	Used with the -s argument, performs an unattended (silent) installation using the response file that you specify.  If you do not specify a response file, or if the path or filename is incorrect, the default non-silent GUI or command line installation is used instead.

Some examples:

- ♦ To perform a command line installation on a Linux server:  
`sh unzip_location/Disk1/setup.sh -e`
- ♦ To specify a database directory:  
`unzip_location\disk1\setup.exe -l d:\databases\sybase`
- ♦ To create a response file:  
`unzip_location\disk1\setup.exe -s`

- ♦ To perform an unattended installation:  
`unzip_location\disk1\setup.exe -s -f`  
`c:\temp\myinstall_1.properties`